

## FLEX DELINEATOR POST 100

Code: IT-FLEX-100



### WHAT FLEX DELINEATOR POSTS ARE?

Versatile, economic and efficient devices, commonly used to mark lanes and miles of bike ways. These also work to indicate a risk situation, delineate specific areas, work zones or as an ad.

Their main function is avoid vehicles invade prohibited zones, delineate and line reserved areas.

Ideal as safety road delineators and even to create pedestrian crossings.

Useful in parking lots, works, detours, restricted zones, etc.

### FEATURES

- Resistance to impact of vehicles due flexibility.
- Flex delineator post 100 has an exclusive design.
- Base and body produced in Poliflexy®, soft and 100% flexible material that doesn't cause damage to vehicles.
- Withstand multiple run overs.
- Body manufactured in a single piece with cap to avoid enters water rain or garbage.
- Green, orange, white or blue (other color upon request).
- Base in black color with 3 reinforced rivets, to avoid it detach the body.
- Recovers original shape after impact, recovering vertical position.
- Easy to set and replace.
- Lightweight; easy to transport and store.
- Reflective sheeting that help to increase night visibility.
- Anchoring system with 4 screws with anchor (not included).




# FLEX DELINEATOR POST 100

Code: IT-FLEX-100

## MEASURES

Dimensions and other measures are nominal and may vary by + - 2 %.





- |                         |  |
|-------------------------|--|
| <b>Manufactured in</b>  | • Poliflexy® body  |
| <b>Color</b>            | • White, orange, blue or green   |
| <b>General Measures</b> | <ul style="list-style-type: none"> <li>• Base Length: 5.9 in</li> <li>• Base Width: 4.7 in</li> <li>• Height: 39.3 in</li> </ul> |
| <b>General weight</b>   | • 0.560 kg (1.234 lbs)   |
| <b>BASE</b>             |  |
| <b>Manufactured in</b>  | • Poliflexy®   |
| <b>Color</b>            | • Black  |



## ANCHORING SYSTEM

1. Mark the boreholes where the bollards will be placed.
2. Drill the boreholes with a 3/4" drill bit for concrete to a 7" depth.
3. Insert the extralarge anchors in every borehole and mount the bollard.
4. Place the 3/8" x 5.9" flat washer and tighten with a 9/16" socket wrench.

DONE!

-  21 v Ø 3/8" x 5.9" Hex Head Ultrafix Screw
-  3/8" Flat Washer
-  Drilling on the base
-  Ø 0.7" x 5.5" Extralarge Anchors
-  Borehole in concrete



### ANCHORING IN CONCRETE

- Ø 3/8" x 5.9" Hex Head Ultrafix Screw
- Ø 0.7" x 5.5" Extralarge Anchors
- 3/8" Flat Washer