

# BRÍO 1000 PLUS DELINEATOR POST

Code: BBRIO-1000 Plus

## WHAT'S A DELINEATOR POST?

This device is a signaling post, used to indicate a risk situation or delimit specific areas.

**What is used for?** The main function is avoid vehicles invade prohibited zones, demarcate and line up reserved zones that work as safety road delimiters in places as bike lanes, parking lot entrances or to create pedestrian crossings.

**Applications.** Mainly suggested to impede vehicles invade prohibited areas or danger zones.



## FEATURES

- 100 % flexible, creating a resistant device to vehicles' impact.
- Recovers its vertical position and original shape, in case of run over.
- Base manufactured with new generation plastic, withstands up to 25,000 accidental run overs of less than 5 tons.
- Body manufactured in one piece, without extra caps to avoid detachment.
- Manufactured in POLIFLEXY PLUS®, soft and flexible material that doesn't cause damage to vehicles.
- The delineator post is joined to the base, preventing detachment.
- Line color: black.
- 2 prismatic reflective rings protected by the body of the post that guarantee durability of the shining area.
- A safe anchoring to the floor through 4 screws, 4 flat washers and 4 extralarge anchors (sold separately).



# BRIO 1000 PLUS DELINEATOR POST

Code: BBRIO-1000 Plus

## MEASUREMENTS


Dimensions and other measures are nominal and may vary by +/- 2%.

- |                                 |  |
|---------------------------------|--|
| <b>Total</b>                    | <ul style="list-style-type: none"> <li>• Height: 3.2 ft</li> <li>• Top ø. 4.2 in</li> <li>• Base ø 6.8 in</li> </ul> |
| <b>Reflective Tape</b>          | <ul style="list-style-type: none"> <li>• 2 rings of 26.3 in<sup>2</sup> (each)</li> </ul>                            |
| <b>Color of Reflective Tape</b> | <ul style="list-style-type: none"> <li>• Amber or white</li> </ul>   |
| <b>Weight</b>                   | <ul style="list-style-type: none"> <li>• 2.491 lbs</li> </ul>  |

## ANCHORING

1. Mark the position of the boreholes using the base of the post as a template.
2. Drill the designated area with a 3/4" drill bit for concrete to a 7" depth.
3. Insert the anchors on the boreholes and place the delineator post.
4. Insert the 3/8" x 5.9 in screws with flat washer, tighten the 4 screws using a 9/16" socket wrench and...

DONE!

- 
- 21 v Ø 3/8" x 5.9 in Hex-Head Ultrafix Screw
  - 3/8" Flat Washer
  - Leg of the product
  - Ø 0.7 in x 5.5 in Extralarge Anchor
  - Borehole in concrete

