

BRIO 1000 DELINEATOR POST Traffic Beacon

Code: BBRIO-105S

WHAT'S A DELINEATOR POST?

This device is a sign used to indicate a risk situation or delimit specific areas.

What is used for? The main use of this device is avoid vehicles invade prohibited zones, demarcate or line up reserved zones; working also as safety road delimiters in places like bike lanes, access to parking lots or even to create pedestrian crossings.

Applications. Suggested to place in forks, highways, roads, diversions, toll booths, et al.



21 v Ø 3/8" x 5.9 in
Hex Head Ultrafix Screw
Ø 0.7 in x 5.5 in
Extralarge Anchor
3/8" Flat Washer

FEATURES

- 100 % flexible device, resistant to vehicles' impact.
- Recovers its original shape after run over.
- Base manufactured with new generation plastic, withstands up to 25,000 accidental run overs of less than 5 tons.
- Body manufactured in one piece, without extra caps to avoid detachment.
- Manufactured in POLIFLEXY®, soft and flexible material that doesn't cause damage to vehicles.
- The delineator post is secured to the base with 4 button head screws.
- Line colors: yellow and orange (other colors upon request).
- 2 prismatic reflective rings protected by the body of the post to guarantee durability of the shiny area.
- Safe anchoring to the floor through 4 screws, 4 flat washers and 4 extralarge anchors to provide greater security.



BRIO 1000 DELINEATOR POST

Traffic Beacon

Code: BBRIO-105S

MEASUREMENTS


Dimensions and other measures are nominal and may vary by +/- 2%.

- Total**
 - Height: 3.2 ft
 - Top \varnothing . 4.2 in
 - Base \varnothing 6.8 in
- Reflective Tape**
 - 2 rings of 26.3 in² (each)
- Color of Reflective Tape**
 - Amber or white
- Weight**
 - 2.579 lbs

ANCHORING

1. Mark the position of the boreholes using a 3/4" drill bit for concrete, and the base of the post as a template.
2. Drill the designated area to a 6" (15.24 cm) depth, insert the anchors on the boreholes and place the delineator post.
3. Insert the 3/8" x 5.9 in screws with flat washers, then tighten the 4 screws with the help of a 9/16" socket wrench.

DONE!

- 
- 21 v \varnothing 3/8" x 5.9 in Hex Head Ultrafix Screw
 - 3/8" Flat Washer
 - Drilling on the base
 - \varnothing 0.7 in x 5.5 in Extralarge Anchor
 - Borehole in concrete

